



FASTENERS

INFORMATION SHEET

OVERVIEW

Fasteners attach the cladding and insulation panels to the door frame. Diamond Doors recommends and offers fasteners that are a self-drilling #10-16 or #12-16 tek screw. For non-insulated doors, either a ¾" or 1" tek screw is required.

Insulated doors will require either a 3" or 4" tek screw depending on the thickness of insulation used. (We offer a 2" and 3" insulation panel.) These tek screws are available in all Diamond Doors standard colours. The tek screw is fastened through the cladding, through the insulation, and drilled into the frame of the door. The same order is used for non-insulated doors, with the exception of the insulation panel.

The fasteners are powder coated to prevent paint chipping when installed. It is recommended to use a drill instead of an impact to prevent unnecessary paint chipping.

TECHNICAL SPECS

Fastener Type: Self drilling tek screw
Screw Size: #10-16, #12-16, ¾", 1", 3", or 4"
Fastener Colour: See colour chart
Fastener Finish: Powder coating

WARRANTY

The door is free of manufacturing defects in material and workmanship for a period of two years. The door will not warp, crack, or buckle under normal intended use as a door.



FREQUENTLY ASKED QUESTIONS

Can I provide my own fasteners?

If you prefer to supply your own fasteners, Diamond Doors will provide you with the required amounts.

